Setup VM Box

- Required for Devops practise
- Install VM box
- Virtualization helps to run multiple OS on single hardware
- VM machine.
- VM box oracle VM box,
- Download the oracle VM box from site

https://www.virtualbox.org

- VM box site \rightarrow download of VM \rightarrow Windows hosts.
- Start the installation → next.. Finish

Next → Creating the Image

- Open VM box from Program files
- Click on new, go through the wizard
- Output Image created

Next \rightarrow Mapping the image (OS) to VM box

Download the OS - Centos (RHEL)

https://www.centos.org

- Map the downloaded copy of image to VM box
- Select The Image→ settings→ storage → Disk button → showing the image OS (downloaded OS copy)

Next → Installing the Centos OS

- Select the image, click on start in VM box
- Timer runs, before it ends, hit on ESC key on keyboard
- We get "boot:"

linux text

- It helps to install centos in CUI format -
- Press enter
 - [X] its already configured
 - [!] we have to set the configuration -- Target to configure it.
 - [] optional
- Checked with 9 options whatever it was required I done it.
- Wait until a message that says "installation is complete" press return "
- Then PC will restart

Next \rightarrow verify if the installation is successfully.

Login into Image, os using below id

ld root

Password enter the password that was given at the time of installation.

• Shutdown

== We are done with VM box setup ====

Step 1: indentify your network - wired or wireless

step 2. Right click on the network connection that is identified and select the option "Open Netwok and Sharing Center", it will open new window.

step 3: In new windows, look for the option, "Change Adapter Settings" and then click on it.

Step 4 : Identification

Wired --> Realtek

Wireless --> Dell Wireless

Step 5: In VM Box, Please select the image that is required, & click on settings, it will open a window, in that, select "Network"

- Make sure we check the option Enable Network Adapter - Attached to should be Bridged Adapter - Select "Name" based on the network Connection Type(wired or Wireless) - Then expand "Advanced", then change the value of "Promiscuous mode o Allow All - Make sure that "Cable connected" is checked whether it is a wired or wireless connection. Step 6: Start the Image(Linux), and login into PC Step 7: enter command to activate the network, # nmtui - we will get a window, --> select "Activate a Connection" - Make sure that we activate it. - Quit from nmtui window. Step 8: to get IP address use command, # hostname -I or # ip addr show

identify network adapter(enp0s3) --> inet value

or

ifconfig

note: to install this # yum install net-tools